

7
8
9
10
11
12
A
B
C
D
VR assembly (1/2) (AWZ3439:A-51, A-777)
(AWZ3438:A-878)
SPEAKER TERM. assembly
SP-A
SP-B
OWER L assembly
WZ3417:A-51, A-777)
WZ3416:A-878)
HEAD PHONE assembly
SPEAKER SWITCH assembly
DIODE assembly
POWER R assembly (AWZ3420:A-51, A-777)
(AWZ3419:A-878)
POWER SUPPLY assembly
(AWZ3425:A-51, A-777)
(AWZ3424:A-878)
POWER TRANSFORMER
VR assembly (2/2) (AWZ3439:A-51, A-777)
(AWZ3438:A-878)
Figures enclosed in ( )* are for A-878/HEZ TYPE